

7" Two Screen Car DVD Player: Extra Screen

PDM-2727M



20060426

Contents

Contents	2
Safety Instructions	3
View of Front Panel	4
View of Side Panel	5
System Connection	6
Power Supply Preparation	7
Troubleshooting	8
Specifications	9

Safety Instructions




The lightning flash with arrowhead symbol, within a triangle, alerts the user to “dangerous voltage” which could cause electric shock.




The exclamation point within a triangle indicates to the user to read important operating and maintenance instructions in the manual.

Notes

- 1) Read these instructions.
 - 2) Keep these instructions.
 - 3) Heed all warnings.
 - 4) Follow all instructions.
 - 5) Do not use near water.
 - 6) Clean only with dry cloth.
 - 7) Do not block any ventilation openings. Maintain well-ventilated conditions around the product. Do not put product on bed, sofa or anything that blocks ventilation. Install in accordance with the manufacturer's instructions.
 - 8) Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
 - 9) This unit is equipped with a polarized plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong is provided for your safety. If the plug provided doesn't fit in your outlet, consult an electrician for replacement of the obsolete outlet. Removal of the polarized plug will diminish the plugs level of safety.
 - 10) Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
 - 11) Only use attachments/accessories specified by the manufacturer.
 - 12) Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
- 
- 13) Unplug this apparatus during lightning storms or when unused for long periods of time.
 - 14) Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, for example, power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
 - 15) Apparatus should not be exposed to dripping or splashing and no objects filled with liquids, such as vases, should be placed on the apparatus.


Note: Do not touch the color TFT LCD screen by hand directly.

View of Front Panel



- 1. POWER button**
Press to access to or exit from the standby mode.
- 2. -/+ button**
Press to adjust the value of brightness and color
- 3. MODE button**
Press to change the brightness and color level, press and hold for 1-2 seconds to change the aspect ratio.
- 4. Speaker**
- 5. Power Indicator**
In normal playback status, it doesn't indicate and it turns red in standby mode.
- 6. LCD Screen**

View of Side Panel



1. Volume Control

Used to adjust the volume of the headphone and speaker.

2. Headphone Jack

Used to connect headphones for private listening. When the headphones are connected to this jack, the speaker will be turned off automatically.

3. Audio Input Jack

Used for audio input.

4. Video Input Jack

Use for video input.

5. DC 9.5V Output Jack

Used for output power to the master DVD player.

6. DC 9.5V Input Jack

Used to connect the power adapter, including the car adapter.

System Connections

Connect to Master DVD player

1. Make sure that the master DVD player, slave LCD screen and any other electrical equipment are off before connection.
2. Connect the AC adapter to the slave LCD screen and connect the slave LCD screen with the master DVD player using power supply cord with supply power to the master DVD player.
3. Use audio and video cables to connect the slave LCD screen with the master DVD player so that the master DVD player can input audio and video to the slave LCD screen.


Please see the figure below for details.



Note: The AC adapter must connect to the slave LCD screen, or the slave screen will have no power supply.

Connecting to Headphones

Connect the headphones to the right side of the player for private listening.




When headphone is connected, the speakers will automatically turn off.

Power Supply Preparation

Using the AC Adapter


1. Connect AC adapter to the jack marked DC IN on the right side of the slave LCD screen in, as shown below.
2. Plug the two-prong end of the power cord into a grounded electrical outlet.



Note: Turn player's power off before unplugging.

Using of Car Adapter

Connect the Car Adapter Power Plug to the slave LCD screen's power jack and plug the other end to the vehicle's cigarette socket as the figure shows below.



Attention

- Do not operate the unit or view video software while driving a vehicle.
- Place the unit in a proper position for viewing.
- Disconnect the player from the Car Adapter when starting the vehicle.

Troubleshooting

SYMPTOM	HOW TO CHECK
There is no sound.	<ul style="list-style-type: none">- Make sure system connection is correct.- Make sure the speakers are turned on.- Make sure the audio source is correct.
There is no picture.	<ul style="list-style-type: none">- Make sure LCD screen is on and in correct video mode.- Make sure your system connection is correct.- Make sure the video source is correct.

Others possibilities:

Static or other external interference may cause the unit display abnormally. In order to recover normal status, unplug the power-supply cord and then plug it in to reset the unit. If the problems still exist, disconnect the power and consult your service center or a qualified technician.

Specifications

TFT screen size	7 inches
Video System	NTSC
Frequency Response	20Hz-20kHz \pm 2.5dB
Power	DC 120V-50/Hz
Power Consumption	<25W
Dimensions	230mm x 154mm x 22mm (L*W*D)
Weight	0.37kg

DESIGN AND SPECIFICATIONS ARE SUBJECT TO CHANGE WITHOUT NOTICE

"Polaroid" and "Polaroid and Pixel" are trademarks of Polaroid Corporation, Waltham, MA, USA.

For service, support and warranty information, visit www.polaroid.com or in Mexico call 01-800-400-2443.